

Joys Compatibles

Pad Controller

8BITDO pad collection

Akishop PS360+

Bigben Pad Luxe PS3

Bowink Wireless Bluetooth Controllers

CSL - Gamepad USB SNES

CSL – USB Wireless Gamepad (Modell 2016)

CronusMAX Adapter (Xbox360 Out)

Freebox controller

Gen Game S3

Gen Game S5

Hori Pokénn Tournament for Wii U

iBuffalo SNES Classic USB Gamepad

Konix PS3/PC

Logitech Rumblepad 2 USB

Logitech Cordless Rumblepad 2 (with 2.4GHz RF USB dongle)

Logitech Gamepad F310 (USB)



see 8bitdo on recalbox

Select "Shanwan" in config

analogique mode


Works with cable, require a bluetooth dongle for bt mode

Can be paired, but is acting weird in the configuration. Recognized as a keyboard, if both analog stick are pressed. In the configurations, it doubles the pressed button for every entry. Does not work in a game, just in the main menu



The 2 Special Button "Turbo" and "Clear" works well

SteelSeries Free Mobile Wireless	✓	require a bluetooth dongle
SteelSeries Stratus	✗	Bluetooth can be "paired" but is not detected afterwards
Subsonic Bluetooth Controller PS3	✓	(gasia driver) see [[PS3 controllers
Thrustmaster T-Wireless	✓	
VZTEC USB Double Shock Controller Game Pad Joystick VZ-GA6002	✓	
Wii U Pro Controller (With bluetooth dongle)	✓	
XBox One (USB only)	✓	
XBox360 USB	✓	
XBox360 Wireless	✓	
Xbox controller from original Xbox with USB modification	✓	
Xiaomi Controller	✓	need to pair after every disconnect
Official Nintendo Wiimote	✓	
Official Nintendo Wiimote Classic Controller	✓	
Official Nintendo Wii U Pro Controller	✓	
Official Nintendo Switch Pro Controller	✓	LED`s always blinking
Zero Delay USB Encoder PC/PS3 controller	✓	
Zero Delay USB Encoder Remix PC/PS3 controller	✓	
Trenro Dual PlayStation/PlayStation 2 to PC USB Controller Adapter	✓	Generic USB adapter for 2 PS1/PS2 PAD controllers
Sony PlayStation official PAD controller	✓	with Generic USB adapter for 2 PS1/PS2 PAD controllers
Sony PlayStation official Dualshock PAD controller	✓	with Generic USB adapter for 2 PS1/PS2 PAD controllers
Sony PlayStation Brandery compatible Dualshock PAD controller	✓	with Generic USB adapter for 2 PS1/PS2 PAD controllers
Gamesir G3S	✓	pad can be configured in menu but behaves weirdly in game



Hori Fighting Commander
iNNEXT IN-Y-D002-024
KONIX KX-CT-PC
Moga Pro




Arcade Stick

8BITDO FC30 / NES30 Arcade Joystick (USB only)
DATEL ARCADE PRO JOYSTICK inc RAPID FIRE for PS3 Xbox360 PC
LIONCAST arcade fighting stick for PS2, PS3, PC
MadCatz Fightstick TE-S for PS3
MadCatz Fightstick Alpha PS4
MadCatz Arcade Fightstick Tournament Edition 2 PS3/PS4
MAYFLASH XBOX 360 / PS3 / PC Arcade Fighting Stick V2
Mayflash PS2 PS3 PC USB Universal Arcade Fighting Stick
Mortal Kombat - Edition Ultimate PS3
PlayStation 3 HORI Real Arcade Pro. 3
PlayStation 4 HORI Real Arcade Pro. V
PXN - 0082
Venom - Arcade Stick PS4, PS3
XBOX 360 / PS3 / PC Arcade Stick Tournament Edition (round1&2)
XBOX 360/ PS3 /PC Arcade QanBa Q4 RAF
Xbox 360 / PC Street Fighter IV FightStick
Xbox 360 / PC HORI Fighting Stick EX2 USB
HORI Fighting Stick MINI 3 for PS3
HORI Fighting Stick MINI 4 for PS3,PS4
HORI Real Arcade Pro. 4 Kai for PS3,PS4



4.0.0-beta1
4.0.0-beta3
4.0.0-beta6



JLF-TP-8YT (Sanwa) Arcade Joystick
Pushbutton SL-CV
Halo Button

